



Polaris 360 Universal Wall Fitting Connector Assembly Installation Instructions

1. Remove and discard the old parts that connect the 360 hose to the pool wall.
2. Unscrew the universal wall fitting from the quick disconnect. Screw the universal wall fitting into the 1-1/2" return line by hand.
3. Turn the quick disconnect into the universal wall fitting by hand. Once the universal wall fitting is secure, the quick disconnect can be removed without removing the universal wall fitting.
4. Put the hose nut onto the end of the quick disconnect.
5. Push the hose onto the quick disconnect and screw the hose nut onto the hose.

